



# EasyWipe

## Disposable Wiping System

The EasyWipe Disposable Wiping System provides the flexibility and ease to create customized cleaning wipes by simply adding the cleaner, disinfectant or sanitizer of your choice.

### Features & Benefits

- Specially-treated wipes do not bind with cleaning chemicals or disinfectant actives. Can be used with a variety of Diversey cleaners, disinfectants and sanitizers
- High quality fibers allow for easy pick-up and removal of dirt, dust and other soils. Use on all hard, nonporous surfaces that are outlined on the chemical label
- Individual wipes in an enclosed system reduce the risk of surface cross-contamination, chemical splashes and spills. Bucket can be re-used with an EasyWipe refill
- Allows for dispensing of individual cleaning wipes, no wringing required. Helps reduce chemical waste providing an accurate chemical load on each wipe
- Bucket closure system allows the wipes to be used across shifts, saving time and money. Ideal for facilities with no laundering capability

### Applications

- Healthcare, Education, Retail, BSC, Government, Lodging







The EasyWipe Disposable Wiping Systems is the perfect choice for dust and dirt removal in facilities with no laundering capabilities. Pre-wetted disposable wipes can replace traditional spray-and-wipe cleaning.

### Use instructions

- Ensure the EasyWipe Disposable Wiping System is compatible with the desired type of chemical solution. Read Safety Data Sheet (SDS) and test the chemical solution with the wipes to determine compatibility.
- Understand any hazards related to the chemical solution and its use by consulting its SDS. Follow all applicable safety advice and use appropriate protective equipment. For questions about safe chemical solution use, contact your supervisor or site occupational safety professional.
- Fill out the label with all information about the added chemical solution or apply the appropriate aftermarket label to the bucket. Note: This label does not replace the manufacturer or supplier's SDS.
- Add 16 fluid ounces of selected solution to an empty EasyWipe System container.
- Place a new roll of EasyWipe wipes into the container to absorb the solution.
- After allowing one minute for the initial solution to be absorbed into the roll of wipes, add an additional 48 fluid ounces of selected chemical solution (64 fluid ounces total) to the EasyWipe System container.
- Thread the end of the wiper from the CENTER of the roll through the lid opening. Snap the lid on.

Technical data	EasyWipe
Color/Material	White, Meltblown Polypropylene
Size	12 in x 10.5 in (30.5 cm x 26.67 cm)

Product	Pack size	Dilution	Product code
EasyWipe	125 wipes EasyWipe Disposable Wiping System	Ready-to-use	5768748 
EasyWipe	125 wipes EasyWipe Disposable Wiping System Refill	Ready-to-use	5831874 

### Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at [www.diversey.com](http://www.diversey.com) or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.