



EasyWipe Disposable Wiping System

Pre-wetting Instructions

How to Use Diversey Cleaners and Disinfectants with EasyWipe Disposable Wiping System

Diversey cleaners and disinfectants, both concentrates and ready-to-use (RTU) products, may be used with the EasyWipe Disposable Wiping System. Use of Diversey cleaners and disinfectants with the EasyWipe Disposable Wiping System provides customers with high performance cleaning and the convenience of using a disposable wipe for cleaning and disinfecting hard non-porous surfaces.

Following are directions on how to use Diversey cleaners and disinfectants with the EasyWipe Disposable Wiping System:

1. Add 16 fluid ounces of selected disinfectant or cleaner solution to an empty EasyWipe System container.
2. Place a new roll of EasyWipe wipes into the container to absorb the solution.
3. After allowing one minute for the initial solution to be absorbed into the roll of wipes, add an additional 48 fluid ounces of selected chemical solution (64 fluid ounces total) to the EasyWipe System container.
4. Pull wipe from the center of the roll up about 5 to 6 inches and push through the center opening of the snap-on lid. Snap the lid closed on the EasyWipes System container and begin using the wipes. Close the center-opening cover after each use to prevent loss of cleaning/disinfectant solution. Refer to the original product label for directions for use and surface contact times.
5. Properly label the EasyWipes System container with the correct in-use label.
6. Unless otherwise listed, the storage stability of disinfectants used with the EasyWipe Disposable Wiping System is 24 hours.



Improved / Accelerated Hydrogen Peroxide - 28 days

Quaternary Ammonium Compounds - 14 days

Sodium Hypochlorite RTU - 21 days

Please contact Customer Technical Service if there are any questions at 1-800-558-2332, Option 5.